

DIRECTIONS FOR RECHARGING AND FOR USE

CHARGING USING MAINS OR 12V SUPPLY

Make sure to turn off the lantern before recharging. The unit should not be used when it is being recharged as this can damage the battery.

The red light indicates that a charger is connected and that the battery is fully charged.

Place the lantern in a well ventilated area during recharging.

Do not exceed the recommended charging time which is 3 hours from the mains supply and 5 hrs from a 12V car charger.

There is a risk of damage if these instructions are not carefully followed.

Do not completely discharge the battery before recharging as this will decrease the battery life.

Never attempt to use the battery charger provided for other products.

Never leave your lantern in extremely high temperatures while recharging.

It is advisable to use the lantern from time to time in order to maintain good working condition.

Always recharge after use.

Recharge the lamp when not used for a period of longer than 3 months to maintain the condition of the battery.

With proper care it should be possible to recharge the battery more than 600 times.

CHARGING USING THE WIND UP METHOD

- 1 Turn off the light
- 2 Unfold the wind up arm
- 3 Hold the torch body with one hand and with the other rotate the wind up handle in either direction and at a steady pace
- 4 Fold the handle back against the torch body

TO USE THE TORCH

Press the 'on' button

The torch can operate in 3 modes:

4, or 12 LEDs ON at a time and off
Simply switch the torch on and off to cycle its operation to your desired mode.

The battery is non-replaceable.

Do not short-circuit the battery terminals.

Do not allow any part to come into contact with heat or a direct flame.

Do not allow water to come into contact with the batteries or wiring.

This is not a toy, keep this product out of reach of small children.

BATTERY DISPOSAL

When the battery does expire it should be removed from the lantern for recycling.

Waste electrical products should not be disposed of with general household waste.

Please recycle where facilities exist.

Check with your local authority or retailer for recycling advice.

SPECIFICATIONS:

Battery - Rechargeable NiMH 3.6 V 800mAh
Dynamo powered - rotating the handle for 1 min will provide enough power for 20 mins

CHARGING TIMES:

Mains charger - 3 hrs

Car charger 12V DC - 3 to 5 hrs

After recharging with either of the supplied accessories there is enough power for:

12 LEDs: up to 20 hrs

PRODUCT SIZE

25.5cm (H) x 10.6cm (D)

